



### **DESCRIPTION**

The groundbreaking subbass MF-15 is an innovative development with exceptional deep bass response, concomitant compact size. This allround talent distinguishes for a variety of applications and total free scaleability.

The special Manifold-constuction provides optimised radiation impedance for much more than 2 octaves to a 15" ultra long excursion driver. Minimal power compression and laminar airflow is ensured by the specially developed front fabric.





#### **FEATURES**

Due to the digital implemented algorithm with multiband limiting function, the active Manifold works up with all music contents easily, even those with very low crest factors.

- Manifold construction
- +/- 16mm linear cone excursion
- Ultra low distortion
- DSP controlled amplifying unit
- Cardioid Mode
- Optional rigging hardware





### **APPLICATIONS**

The MF-15A can be operated in cardioid mode just at the touch of a button. With at least one additional subwoofer used in the 80Hz or 100Hz configuration a backward attenuation of more than 20db could be realised.

- Scaleable FOH-System
- Clubs / Discos
- Portable PA for Bands / DJs
- Sidefill / Drumfill
- Line Source
- Phased Array / Beamforming





# **PERFORMANCE**

System

Configuration

**Electronics** 

**Signal Processor** 

**Frequence Response** 

Sensitivity

Connection

High power subbass

with Manifold technology

 $1 \times 15$ " ultra long excursion driver

with 4" VC and hardened cone

Aluminium demodulation rings

1600W RMS amping power

24bit ADC/DAC, 48kHz samplerate

35-200Hz (+/- 3db)

98db / 1W / 1m

104db / 1W / 1m - stack of 4

XLR in / out, Powercon in / out





# **PHYSICAL**

**Enclosure** Rigid braced construction

of special 15mm lightweight-wood

**Finish** High-Density polyurethane-coating

Black

**Front Cover** Weather-resistant front fabric

on coated 1.5mm perforated steel

**Dimensions** Inches Millimeters

 Height
 14.8
 377

 Width
 25.9
 657

 Depth
 34.3
 872

**Weigth** Pounds Kilograms

67.5 30.6

